

1. Scan the barcode to reset the scanner to factory default settings:



恢复默认设置 %%SpecCode93

2. Remove the scanner from the existing Bluetooth connections from your device, and scan the below codes:



%%SpecCodeAA



%%SpecCode99

3. Search for new Bluetooth Connections on your device, and select ScanAvenger HID from the list. Once you click on it, the pairing will be completed.