How to connect your scanner Store mode **Frequently Asked Questions** Troubleshooting your scanner How to connect your scanner using German: **Step 2:** Chose how many characters you wish to hide Led & Buzzer via Bluetooth to a mobile phone **USB Wireless Dongle: Trigger Modes 8** 回器匣 Never sleep: (Scan only 1 barcode) Wireless Barcode Scanner Scanner type CMOS tablet or other Bluetooth devices set to Store mode, each tim I. Can it automatically open a website page, There are two different trigger modes: 2.4G Mode - laptop/computer Some barcode types are disabled in the default configurati after scanning a QR Code? Quick Start Guide you scan a barcode, it will be Light source Red Light LED 525 ±10nm 翻 Scanner ON and connecte Check the user manual for further information or email a 1. Power the scanner by pressing the button stored in its internal memo 1. Scan: 1. Manual Trigger CPU 32-bi verse barcodes are barcodes that have white Red LED ON To upload all the store he basic idea is that the scanner acts as an automatic helpdesk@scanavenger.com 2. Insert the USB donale in the USB port of your device Spanish: round. The scanner is configured by default to keyboard. You have to click where you want the data to be 3. Wait 30 seconds for devices to pair automatic for more information No light ON 回器区 Scanner not connected **Led & Buzzer** Resolution 1D≥3mil.2D≥8.7mil@PCS9 Each time you scan a barcode, it will transmit the data as it For any issues connecting the scanner to the Wireless USB Dongle please follow the below you would be typing on a keyboard. Your devices will 部 recognize the scanner as a keyboard. Please note that this will not impact your keyboards functionality. Blue LED ON Scanner ON and connected Depth of field 10mm-500mm 1. Unplug USB Dongl Red LED ON 2. Scan Below Barcode Scan mode Manual, Auto Sense . Sense Mod 識 No light ON or wireless connection succes Scan angle Roll $\pm 360^{\circ}$, Pitch $\pm 60^{\circ}$, Skew $\pm 70^{\circ}$ SOUND SETTINGS Language settings 2. When trying to scan, my scanner makes multiples 5 short beeps Print contrast ≥25% beeps, without outputting anything (low frequency) Turn sound off Configuring your scanner Battery without electricity Power ON/OFF Wireless 2.4GHz = 150meters, Bluetooth 2.4G Mode - laptop/compute Why does this happen? and stop scanni 3. Scanner light will be flashing blue. This means you can Connect it to your mobile device. On your mobile/tablet ican common barcode, paire If you need to clear all the The number of beeps and the LED on the back of your distance 30meters (open distance) Hide 2 bits scanner will help you identify why this is happening. The go to Bluetooth devices, search for "ScanAvenger HID" BUILT TO ENDURE Storage 16Mb **SLEEP TIME SETTINGS** 5 short beeps (low frequency) and stop scanning Wireless disconnection (low frequency Battery without electricity Scan below barcode check the extended user manual, or email us at Battery capacity 2200 mAh (1200 mAH for SA1100) helpdesk@scanavenger.com for more detail Mini Scanner LED Ligh Charging time Approx. 3 hours 3 short beeps Follow the steps below to configure your scanner to Wireless disconnection device. To fix this, please follow the Dongle/Bluetooth 1 Small and Medium light turn on when scanner is Continuous ≥16 hours (low frequency hide characters: 2. Large light turns on when the scanner is connected 3. Medium light flashes once when successfully working time Step 1: Chose if you want to hide from the back or from Low volume If you wish to exit Store Communication USB, Wireless 2.4G, Wireless ue light on the scanner should be turned on, indicating that 国以回 Mode, scan the barcod This means that your scanner is out of battery. Please In order to correctly use the barcode scanner, please your scanner is connected to the dongle." * If scanner is Bluetooth 4.2 read the instructions carefully. It is advised to keep thi Bluetooth Mode and you want to revert back to previous Bluetooth devices on your mobile and go through the above Hide Front of Barcode digits Power supply DC 5V@200mA (work) manual for future reference. No part of this publication steps again. For Bluetooth SPP and BLE Modes please contact connected dongle, all you need to do is scan the 2.4G Mode may be reproduced or distributed in any form without ne barcode to revert to normal Operating temp 0°C to 50°C 製鋼 3. Will ScanAvenger barcode scanners work with any Inventory Management Software? written permission from ScanAvenger If at any stage you accidentally scan configuration codes and the scanner stops working, please email us at Storage -30°C to 60°C To test, open a word document or notes and try scanning To test, open a word document or notes and try scanning ScanAvenger reserves the right to make the fina Humidity 5% to 95% (non-condensing a normal barcode (not a configuration barcode from normal barcode (not a configuration barcode Your ScanAvenger barcode scanner will work with most Inventory Management Software. That being said, some Inventory Management Software developers restrict what barcode scanners will work. We recommend checking their helpdesk@scanavenger.com interpretation of the above statement. If you come acros Hide Back of Barcode digits **3000000** the user guide). If you have any guestions about setting up for the full reset process. Drop Height 1.5mCE, from the user quide). any issues with your product, please confact us via ema or configuring the scanner please email us at If you have any questions about setting up or at helpdesk@scanavenger.com
When contacting our helpdesk please make sure
you mention your order number and scanner model. For an extended user manual or any question Certificate FCC, RoHS For an extended user manual or any configuring the scanner please email us at please email us at V9.3 (M9) website for more information. If you're unsure, do not questions, please email us at Our helpdesk operates 24/7 - 365 days a year. helpdesk@scanavenger.com hesitate to reach out to us Our helpdesk operates 24/7 - 365 days a year helpdesk@scanavenger.com.