

SCANAVENGER

To change your ScanAvenger 1D or 1D&2D scanner sound setting, please scan the configuration barcodes corresponding to your preferred setting.

Turn off sound:



%%SpecCode94

Low volume:



%%SpecCode95

Middle volume:



%%SpecCode96

SCANAVENGER

High volume (Default):



%%SpecCode97

Buzzer frequency 2K (Default):



%%SpecCode7C

Buzzer frequency 2.7K:



%%SpecCode7D